



Maintenance of SD/MS Overpressure filter

The overpressure in the compartment shall, when the two filter elements are new, be approx 30 Pascal. This can be monitored by looking at the pressure gauge in the filtered compartment.

The sealing of doors and windows must be improved if the overpressure does not reach correct level.

The filter elements must be replaced when the overpressure is 10 Pascal or less.

When replacing filter elements, it is recommended that the pre-filter (530-011) is replaced first. Then replace the absolute filter (530-012) after approx one week. The life-length of the absolute filter is significantly prolonged by this procedure.

Also remember to clean or replace the humidity separator (530-010).

Do not clean or re-use the used filter elements 530-011 and 530-012! Such actions are hazardous for the health of the personnel in the filtered compartment!